

Interfacial Shear Strength (IFSS) Module for LEX820





The Dia-Stron Interfacial Shear Strength module (IFSS) is an interchangeable module for the LEX820 high resolution extensometer used to measure the debonding force of micro-droplets on single filaments and fibres.


General Information

Principal Features

- 50mm linear travel
- Highly accurate speed control
- 2.5N & 20N load cells available
- Standard set of shearing plates

Principal Benefits

- Exceptionally smooth travel
- High positional repeatability
- Detailed debonding data



Above: Lyocell fiber with polypropylene droplet (Courtesy of Hochschule Bremen)

Introduction

Fibre-matrix interfacial properties are critical to achieving high composite material performance. The IFSS module is an interchangeable accessory designed to measure the debonding force of microdroplets on single filaments and fibres.

The IFSS measurement is based on the universally recognised micro-bond method, which evaluates the interfacial properties between matrix resins/epoxies on fibres and filaments commonly used in composite materials. The IFSS method can be applied to various fibre and filament types: glass, carbon, ceramic, aramid, basalt or natural fibres.

UK office 9 Focus Way | Andover | Hampshire | SP10 5NY | UK t: +44 (0)1264 334700 e: <u>sales@diastron.com</u> US office 9 Trenton Lakewood Road | Clarksburg | NJ08510 | USA t: + 1(609) 454-6008 w: <u>www.diastron.com</u>

LEX820

3 – 53mm
0.01 to 2.6mm/sec
0 to 2.5N or
0 to 20N
0.05mN (2.5N)
0.5mN (20N)
1µm
50µm
±0.1% full scale

Shearing plates

Standard

slot sizes

shearing plate

50µm

80 µm

100 µm

200 µm


Specifications


IFSS Module

The IFSS module uses interchangeable precision laser cut tungsten plates to support the micro-droplet whilst the specimen is withdrawn through. The force being applied by the micro-droplet to the plate is recorded by the load cell until interfacial failure. The sample is secured at the other end using the Dia-Stron one-part plastic tab system and held in place using pneumatic sample covers.

Dedicated software – UvWin

UvWin 4 software controls the IFSS system. Method parameters can be easily edited within the software. UvWin enables automatic correction for system compliance.





UvWin also offers a number of integrated data processing tools to analyse the data. The raw data can also be exported.

Sample Mounting

Samples are mounted using the Dia-Stron one-part plastic tab system. Please note: it is the responsibility of the user to apply micro-droplets using thermoplastics or thermosets on the fibre when using the IFSS module.

LEX820 Instrument

Content

IFSS Module UV1000 Control unit PU1100 Pneumatic unit UvWin software for Windows OS

Requirements	
Power Supply	85-265vac 47-63Hz, 100W
Compressed Air	Dry & clean
	• 4.5 Bar
	• 20 l/min
Computer	 OS: Windows 7, 10 1 x USB port